

Vyberte si čočku ZOOM pro váš telefon

typ telefonu	ZOOM	typ telefonu	ZOOM
Alcatel OT311	Z-112	Samsung SGH C-100	Z-110
Alcatel OT511	Z-112	Samsung SGH D-410	Z-101
Alcatel OT535	Z-111	Samsung SGH D-500	Z-108
Alcatel OT735	Z-111	Samsung SGH R-210	Z-102
Alcatel OT756	Z-106	Samsung SGH X-100	Z-111
LG L3100	Z-108	Siemens A65	Z-110
		Siemens A70	Z-109
Motorola C205	Z-107	Siemens A75	Z-110
Motorola C350	Z-102	Siemens AX72	Z-110
Motorola C450	Z-102	Siemens AX75	Z-109
Motorola C550	Z-102	Siemens C65	Z-110
Motorola C650	Z-103	Siemens C72	Z-105
Motorola E365	Z-101	Siemens C75	Z-108
Motorola E398	Z-101	Siemens CF110	Z-111
Motorola Slvr L2	Z-106	Siemens CT65	Z-110
Motorola Slvr L6	Z-106	Siemens CT70	Z-110
		Siemens CX75	Z-108
Nokia 1110	Z-102	Siemens M50	Z-105
Nokia 1600	Z-105	Siemens M55	Z-104
Nokia 2100	Z-102	Siemens M75	Z-106
Nokia 2300	Z-102	Siemens MC60	Z-105
Nokia 2600	Z-110	Siemens ME45	Z-110
Nokia 3100	Z-109	Siemens ME75	Z-108
Nokia 3120	Z-105	Siemens MT50	Z-105
Nokia 3200	Z-105	Siemens S35	Z-109
Nokia 3220	Z-103	Siemens S35i	Z-109
Nokia 3510	Z-104	Siemens S45	Z-109
Nokia 5110	Z-107	Siemens S55	Z-105
Nokia 5140	Z-105	Siemens SL45	Z-110
Nokia 5140i	Z-105	Siemens SL45i	Z-110
Nokia 5210	Z-112	Siemens ST55	Z-108
Nokia 6020	Z-103	Siemens ST60	Z-108
Nokia 6021	Z-103		
Nokia 6030	Z-104	Sony CMD-J5	Z-109
Nokia 6111	Z-108	Sony CMD-J6	Z-109
Nokia 6220	Z-105		
Nokia 6230	Z-105	Sony Ericsson D750i	Z-101
Nokia 6230i	Z-105	Sony Ericsson J200	Z-111
Nokia 6510	Z-112	Sony Ericsson J210	Z-111
Nokia 6610	Z-110	Sony Ericsson K300	Z-111
Nokia 6610i	Z-110	Sony Ericsson K300i	Z-111
Nokia 7360	Z-106	Sony Ericsson K600i	Z-108
Nokia 8310	Z-112	Sony Ericsson K608	Z-108
Nokia 8800	Z-111	Sony Ericsson K750i	Z-101
		Sony Ericsson T100	Z-107
Panasonic GD67	Z-104	Sony Ericsson T105	Z-107
Panasonic GD95	Z-102	Sony Ericsson T230	Z-110
Panasonic X300	Z-104	Sony Ericsson T290i	Z-109
		Sony Ericsson T600	Z-109
Philips 162	Z-107	Sony Ericsson T610	Z-101
Philips 350	Z-110	Sony Ericsson T630	Z-106
Philips 355	Z-110	Sony Ericsson V600	Z-108
Philips 755	Z-101	Sony Ericsson W550i	Z-101
Philips Fisiso 820	Z-103	Sony Ericsson W800i	Z-108
Sagem MY X-1	Z-102		
Sagem MY X-2	Z-107		